













NovoTouch




Quick Start Guide

(For LK6530i, LK7530i and LK8630i models)


Package Contents

			
Display	VKA05 OPS Module (with Antenna)	Remote Control	Power Cable
			
Wall Mount	VGA Cable	USB Cable	Audio Cable
			
Stylus x 3	Documentation CD	Batteries	Quick Start Guide

Installing the OPS Module


- 1 Remove the 2 screws securing the slot cover onto the display, and then remove the slot cover.**

- 2 Slide the OPS module into the OPS slot.**

- 3 Tighten the two captive screws on the OPS module until the module is properly secure in the display, and then install the antenna.**


Display Overview (Front)



- | | |
|--|---|
| 1 Magnetic Stylus Holder | 6 Input Source / Settings Button |
| 2 IR Sensor (for Remote Control) | 7 Volume Down Button |
| 3 Power Button / Status Indicator LED | 8 Volume Up Button |
| 4 Home Button | 9 USB 3.0 Port |
| 5 Back Button | 10 USB 2.0 Ports x 2 |


Display Overview (Rear)




- | | | |
|---------------------------------|------------------------------|--------------------------------|
| 1 Right Handle | 6 Power Socket | 11 HDMI Out Port |
| 2 Windows OPS Slot | 7 Speakers | 12 USB 2.0 Port |
| 3 Wall Mount Screw Holes | 8 Antenna Connector | 13 HDMI In Port 1 (2.0) |
| 4 Left Handle | 9 Power Indicator LED | 14 HDMI In Port 2 (1.4) |
| 5 Power Switch | 10 microSD Card Slot | 15 Touch Port 1 |

Ports and Connectors (Right)

With Android OPS Module Installed





Ports and Connectors (Bottom)




- | | | |
|-------------------------------|--------------------------------|---------------------------------------|
| 16 DisplayPort In Port | 21 LAN (RJ-45) Port | 26 Audio Out Jack |
| 17 VGA In Port | 22 HDMI In Port 3 (1.4) | 27 USB 2.0 Port |
| 18 USB 3.0 Port | 23 Audio In Jack | 28 AV In Port |
| 19 Recovery Button | 24 Touch Port 2 | 29 RS-232 Port |
| 20 USB 3.0 Ports x 2 | 25 Coax Out Jack | 30 [DISABLED] LAN (RJ-45) Port |

Connections



Remote Control




- | | |
|---------------------------------------|----------------------------|
| 1 Power | 14 F1 - F12* |
| 2 Windows Menu* | 15 Mute |
| 3 Spacebar* | 16 Close Window* |
| 4 Numeric Keypad | 17 Switch Window* |
| 5 Display Information Button | 18 Function Button |
| 6 Input Source | 19 Home Screen |
| 7 Lock/Unlock Buttons and Touchscreen | 20 Settings Menu |
| 8 Blank Screen | 21 Freeze Screen |
| 9 Lock/Unlock Buttons | 22 Backspace |
| 10 Navigation Buttons | 23 Lock/Unlock Touchscreen |
| 11 Quick Draw | 24 Back |
| 12 Page Up/Down* | 25 Volume +/- |
| 13 Function Buttons | |


*Only functional when the optional Windows OPS unit is installed into the display.

Getting Started


Plug the power cable into the display and a power source.



Turn the power switch on, and then press the power button on the display or remote control.



Home Screen



- | | |
|----------------------------------|-------------------------|
| 1 Remote Viewer Presentation App | 5 Tools Menu |
| 2 Web Browser | 6 All Apps Menu |
| 3 Note Drawing App | 7 File Management App |
| 4 Input Source Menu | 8 Android Settings Menu |



Vivitek America

46101 Fremont Blvd, Fremont, CA 94538
U.S.A.
T: +1-510-668-5100
F: +1-510-668-0680

Vivitek Asia

7F, No. 186, Ruey Kuang Road, Neihu, Taipei 11491
Taiwan R.O.C.
T: +886-2-8797-2088
F: +886-2-6600-2358

Vivitek Europe

Zandsteen 15, 2132 MZ Hoofddorp
The Netherlands
T: +31-20-800-3960
F: +31-20-655-0999

www.vivitekc.com